Connect. Adjust. Save.

WI-FI USER GUIDE

CONTENTS

New account

Create an account

Create an account.
Use your email as your user name. Please read and agree the terms and conditions to open your account.

Your account is ready.
You can now add and register your Adax heaters and/or Smart Wi-Fi plugs.

Register heater

Register your heater and/or
Smart Wi-Fi Plug. Follow the
instructions given.

Note!
Your phone/device
must be connected
to the internet, through a
Wi-Fi connection on your
2,4 GHz band. SSID/Network
name must be your
2,4 GHz band.

With the latest firmware
the system should connect
automatically.
With an older version of
firmware you will need to
manually connect to
your heater. Please find
instructions below.

For manual installation
of your heater, you must log
into the heaters network.
The heaters SSID/network
name is SH-ADAX-XXXXX
and the password is
"magicpass123".

If you cannot find the
SH-ADAX-XXX on your list,
it is recomended that you
switch the Wi-Fi OFF and ON
to refresh the list of
available networks.

When the heater is connected
- go back to the Adax Wi-Fi
app to complete registration.

Register heater

The app is searching and registering your heater. This process can take up to 20 seconds.
If the registration fails, and you are asked to try again, please check that network name/SSID and password is correct.
Remember that the SSID has to be your 2,4 GHz band.

Your heater is now registered to the app. We recommend that you give the heater/ product a name, ex. "Living rom", "Kitchen" or "Office".

Only for Android:
Register your heater to a zone, name the zone where you place your heater. If you have several heaters linked to the same zone, you can control all heaters with the same setting and schedule.

Note!
For IOS the heater is connected to a Zone from Zone in main menu.

Main view

Settings of your heater/
zone. The numbers indicate
(15/20°C), e.g. the temp-
erature the heater is set to.
Adjust up or down with "+"
or "-". The number (23.2°C)
is the actual "room" tem-
perature. The three symbols
below from the leftside:
"Scheduling" - here you can
set a "Week program".
The "hand icon" in the
middle is for manually
control of the temperature.

The last symbol is "Away"
mode where you can set
a fixed temperature if you
leave your home for a longer
periode or go on vacation
etc.
If you have several
heaters/zones installed to
your Adax Wi-Fi App, you
can change view between
heaters/zones by swiping
left or right in the window.

Menu

Main menu in the
upper left corner gives you
access to:

1. Account info
2. Zone settings
3. Device – Add and view
   details for your heaters
   and plugs.
4. Schedules – Add and edit
   weekly programs.

Account

Account: Account details,
version number of app etc.
Account ID is needed for
support.

Zones

Add and manage your
different zones.
The App can manage
several homes/locations,
like "House", "Cabin", or
"Appartment".
In a "Home" you can add
several zones like "Living
room", "Kitchen" and/or
"Bedroom".

If you click on "Home" from
main view in Zone, you can
edit the name and invite
other users to manage the
settings of your heaters.

Zones

When you click on zone
"Living room" you will find
several settings and
options. First you can edit
and change the name
of the zone.
Feature list:
Temperature monitoring,
in "ON" mode it will send
you push messages when
the roomtemperature
is changing.
"Child lock" – lock the
options to manually change
the temperature on the
heaters thermostat.

"Open window detection"
– the heaters detects if the
temperature quickly drops
and will set the heating
temperature to 7°C, when
the room temperature
stabilizes the heater will
start to heat as normal.
"Adaptiv heating start"
When you set teperature
to 22°C at 16:00 the heater
will know when to start
heat to reach 22°C at 16:00.
In this view you can also go
directly to "schedule" for
this zone and "devices"
linked to the actual zone.

In this view "Device" you
can add and manage devices/
heaters linked to a zone.
Note that the devices has
to be installed before you
can manage devices.

Week program
for zones

In this view "scheduling"
from zone you can edit and
mange your weekly
programs.
Set individual temperature
for comfort and reducued
temperature in a zone.


Edit and change week
program.

- Set interval by
  choosing days.
- Set start and end time.
- Set heating mode –
  comfort or other preferred
  heating modes.

To set different heating
modes during the day
and week, you must repeat
the process to cover
the whole day.

Product from Mainmenu

Main menu – "Device" here you will find a list of all devices registered to the app by "Home" and "Zone". To add new heaters and other divices click on "Add products".
To edit the name of the device, clik on "Heater 1" to open and view.

When you have clicked on the product, you will get detailed information of your heater, last recorded temperature, current firmware etc.
If there is a new firmware available, you can update the firmware.
Note that you can only update firmware when you are connected to the same network as the heater.

Product

If you have installed a Smart Wi-Fi plug you will find a second icon in your main view. Click on the "socket" to switch from heater to smart plug view. When you see your Smart Wi-Fi plug you can manually set ON/OFF or begin scheduling for the plug.

Product

In this view you set
"Manual" or "Auto" control
of your Smart Wi-Fi Plug.
In "Auto" the plug works
according to your schedule.
The Schedule can be edited
to your preference.

Edit and change week
program for your Smart
Wi-Fi Plug.
Set day and time intervals
with selected mode ON/OFF.

Week program

Main menu - "Schedules"
There are four predefined
schedules/week programs
to choose from. You can
edit any of these programs
to your preference or add
and create a schedule from
scratch with preferred time
and heating modes.

Note!
This schedule only works
for the heaters.
Smart Wi-Fi Plug scheduling
is defined and managed in
another view.

When choosing one of the
weekly programs, you can
view and see details for the
program. Here you can edit
and change the tempera-
tures for different heating
modes with "+" and "-".
To edit days and time
intervals choose "edit",
in the upper right corner.

Edit and change week
program.

- Set interval by
  choosing days
- Set start and end time
- Set heating mode -
  comfort or other preferred
  heating modes.

To set different heating
modes during the day and
week you must repeat the
process to cover all
24 hours of the day.

Away mode

Main view – "Away" mode.

Away mode:
Set "Away" mode
temperature until you
manually stop
the settings.

Manage temperature and
date/time for when you
would like the "Away" mode
to be active.

Delete products

Remove and delete products from your device list. Swipe the product to your left and the "Delete" option will appear.

Delete zones

Remove and delete "Home" or "Room" from your zone list. Swipe the "zone" to your left and the "delete" option will appear.